

HOW TO MEASURE FOR YOUR FREEZEPRO® WRAP

Selecting the right size FreezePro[®] Wrap for your equipment is a lot easier than you might think. All you need is a tape measure, and you are ready to go!

WARNING: When installing or measuring for FreezePro[®] Wrap, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

1. MEASURE FOR EITHER THE (1) CIRCUMFERENCE OR (2) DIAMETER:



CIRCUMFERENCE



DIAMETER

NOTE: It does not matter which method of measurement you decide to use. Just remember that you only need to find your measurement using one of the two ways described above.

DR

2. MEASURE FOR THE DESIRED WIDTH:



WIDTH

NOTE: After finding either the circumference or diameter, measure for the desired width to determine the width measurement of the application you want to insulate.



3. FIND THE RIGHT FREEZEPRO® WRAP:

The CIRCUMFERENCE (length) is 20in and the desired width is 12in = FPW 3012.

FOR EXAMPLE:

<u>OR</u>

The **DIAMETER** (length) is 6in and the desired width is 12in = FPW 3012.

WIDTH

CIRCUMFERENCE	DIAMETER	6in (152mm)	12in (305mm)	18in (457mm)	24in (610mm)
0in - 6in (0mm-152mm)	0in-2in (0mm-51mm)	FPW 1206	FPW 1212	FPW 1218	FPW 1224
6in-13in (152mm-330mm)	2in-4in (51mm-102mm)	FPW 1806	FPW 1812	FPW 1818	FPW 1824
1 3in-19in (330mm-483mm)	4in-6in (102mm-152mm)	FPW 2406	FPW 2412	FPW 2418	FPW 2424
19in-25in (483mm-635mm)	6in-8in (152mm-203mm)	FPW 3006	FPW 3012	FPW 3018	FPW 3024
25in-31in (635mm-787mm)	8in-10in (203mm-254mm)	FPW 3606	FPW 3612	FPW 3618	FPW 3624
31in-38in (787mm-965mm)	10in-12in (254mm-305mm)	FPW 4206	FPW 4212	FPW 4218	FPW 4224
38in-44in (965mm-1118mm)	1 2in-14in (305mm-356mm)	FPW 4806	FPW 4812	FPW 4818	FPW 4824
44in-53in (1118mm-1346mm)	1 4in-17in (356mm-432mm)	FPW 6006	FPW 6012	FPW 6018	FPW 6024

NOTE: Now that you have your measurements, you can use the graph above to help you find the appropriate FreezePro® Wrap part number. Diameter and circumference (length) measurements are listed in the table rows vertically (Y axis) and width measurements are listed in the column rows horizontally (X axis).

