

HOW TO MEASURE FOR YOUR ISOCOVERS ISO-WRAP

Selecting the right size ISOCOVERS ISO-WRAP for your equipment is a lot easier than you might think. All you need is a tape measure, and you are ready to go!


WARNING: When installing or measuring for ISO-WRAP, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

1. MEASURE FOR EITHER THE (1) CIRCUMFERENCE OR (2) DIAMETER:



CIRCUMFERENCE

OR



DIAMETER

NOTE: It does not matter which method of measurement you decide to use. Just remember that you only need to find your measurement using one of the two ways described above.

2. MEASURE FOR THE DESIRED WIDTH:



WIDTH

NOTE: After finding either the circumference or diameter, measure for the desired width to determine the width measurement of the application you want to insulate.



ISOCOVERS

Insulation Systems

3. FIND THE RIGHT ISOCOVERS ISO-WRAP:

The **CIRCUMFERENCE** (length) is 20in and the desired width is 12in = **IW 3012**.

FOR EXAMPLE: **OR**

The **DIAMETER** (length) is 6in and the desired width is 12in = **IW 3012**.

WIDTH

CIRCUMFERENCE	DIAMETER	6in (152mm)	12in (305mm)	18in (457mm)	24in (610mm)
0in - 6in (0mm-152mm)	0in-2in (0mm-51mm)	IW 1206	IW 1212	IW 1218	IW 1224
6in-13in (152mm-330mm)	2in-4in (51mm-102mm)	IW 1806	IW 1812	IW 1818	IW 1824
13in-19in (330mm-483mm)	4in-6in (102mm-152mm)	IW 2406	IW 2412	IW 2418	IW 2424
19in-25in (483mm-635mm)	6in-8in (152mm-203mm)	IW 3006	IW 3012	IW 3018	IW 3024
25in-31in (635mm-787mm)	8in-10in (203mm-254mm)	IW 3606	IW 3612	IW 3618	IW 3624
31in-38in (787mm-965mm)	10in-12in (254mm-305mm)	IW 4206	IW 4212	IW 4218	IW 4224
38in-44in (965mm-1118mm)	12in-14in (305mm-356mm)	IW 4806	IW 4812	IW 4818	IW 4824
44in-53in (1118mm-1346mm)	14in-17in (356mm-432mm)	IW 6006	IW 6012	IW 6018	IW 6024

NOTE: Now that you have your measurements, you can use the graph above to help you find the appropriate ISOCOVERS ISO-WRAP part number. Diameter and circumference (length) measurements are listed in the table rows vertically and width measurements are listed in the column rows horizontally.

4. GO AND ORDER ONLINE:

1. Go to shop.unitherm.com
2. Enter your part number in to the Search bar in the upper left-hand corner of the page
3. Click “**Search**” to get your ISOCOVERS ISO-WRAP Insulation Jacket